



## FLOORSAFE INTERNATIONAL

Anti-slip manufacturers & applicators  
201 Franklin Street Adelaide S.A 5000  
Tel: (08) 841 000 54 Fax: (08) 841 000 58  
Mob: 0412 024 267 [info@floorsafe.com.au](mailto:info@floorsafe.com.au)  
Website: [www.floorsafe.com.au](http://www.floorsafe.com.au)

### FLOORSAFE ANTI-SLIP SYSTEM – APPLICATION PROCEDURES USE ONLY ON: CERAMIC, QUARRY & MOSAIC TILED FLOORS

Thank you for choosing Floorsafe anti-slip system.  
Please read this direction sheet before commencing application.  
Check the contents of this box. Should there be any shortage or damage please call us on 1300 717 769

This Floorsafe anti-slip system pack contains four products.  
Product No.1 ( **pink liquid** ) Product No.2 ( **green liquid** ) & Product No.3 ( **blue liquid** )  
These three products used together will make your slippery tiled floor anti-slip safe.

Floorsafe Product DMC ( Domestic Maintenance Cleaner )  
A specially formulated cleaning product to clean your floor after treatment.

#### **BEFORE YOU START:**

Remove all items from the area to be treated and sweep up all loose debris.  
Lay towelling or protected sheet down beside working area to stand equipment on.  
Make sure you have everything ready before you start. Soft broom, squeegee, water, mop & bucket with plenty of clean cold water.

During application avoid splashing or walking products onto other floor surfaces as staining may occur. **Never allow the products to dry out. Do not apply to hot surfaces.**

#### **DIRECTIONS FOR APPLICATION:**

ALWAYS USE PLENTY OF LIQUID.

IF DOING 8 - 10 SQUARE METRES USE ALL THE LIQUID PROVIDED IN EACH BOTTLE

- 1) Pour out product No.1 in a puddle. Using a soft broom spread the solution over the floor surface to completely wet the floor.
- 2) Whilst product No.1 is wet immediately and carefully pour out product No.2 and brush liquid over product No.1 as above. Brush the liquids carefully around to avoid splashing walls or equipment.  
The two products mixed together will now start to create the anti-slip effect. The leave on time to produce the required anti-slip effect varies from tile to tile. Between 2 – 10 minutes is all that's required. **DO NOT LEAVE PRODUCTS ON FOR LONGER THEN REQUIRED** as over treatment may cause difficulties in cleaning the floor after treatment. To judge this push your foot with weight into the solutions on the floor. As soon as you feel your foot gripping the anti-slip is completed and step 3 should be done as quickly as possible.
- 3) Pour out product No.3 and brush the liquid well in over the wet surface.
- 4) Immediately rinse the floor with **plenty** of clean water. Brush or squeegee as much of the waste liquids down the waste drain outlet.
- 5) Repeat step 4.
- 6) Mop over floor and skirtings with clean water once or twice and leave to dry.

**SHOWER ALCOVES:** If a build up of body fats & soaps exist a second application maybe needed.  
**THE FLOOR IS NOW ANTI-SLIP SAFE AND READY FOR USE.**

Depending on the colour and surface of the tiles a slight dullness or a 'Bloom' maybe visible after the treatment has dried. This is quite normal and will disappear with on-going cleaning.

**SEE ON-GOING MAINTENANCE CLEANER INSTRUCTIONS OVER**

Because the application of these products are out of our control, Floorsafe International cannot and will not except any liability for any injury or damage caused by using these products. NOV 2009