

CARPET INSTALLATION

STAINLESS STEEL FLAT TACTILE SYSTEM



ANTI-SLIP SOLUTIONS

201 Franklin Street Adelaide S.A 5000

PH: 1300 717 769 FAX: 1300 400 434

info@floorsafe.com.au www.floorsafe.com.au



THE FLOORSAFE INTERNATIONAL TACTILE KIT FOR CARPET INSTALLATION



- 1) Place template with holes into position and tape down to hold firm.
- 2) Using hot soldering iron place into template hole and burn out circle. (Approx 3 - 4 seconds)
- 3) Continue to complete the whole template.
- 4) Remove the template.



- 5) Position the circle cut-out template over the holes. Apply enough Tactile adhesive into hole to come just above level of carpet.
- 6) Insert the Stainless steel flat Tactile and turn tactile a half of turn to spread the glue under.
- 7) Continue to complete the template.

To move the template along remove the template and position over the last 3 rows of tactiles. This will insure the template is straight.

ALLOW 2- 4 HOURS DRY TIME
BEFORE ALLOWING FOOT TRAFFIC.